



1. 70 (for the Chalet) + 40 (for each terrace) = 110 concrete paving slabs 50 x 50 x 5 cm (min. 28.8 kg each), normally available in any hardware store must be purchased by the customer and will be assembled by the assembly team

3. Compacted gravel mixture 4/32, horizontal, 25 m² + 14 m², layer height = at least 5 cm.  
Gravel mixture is optional - but recommended (otherwise there is a risk of settlement and moisture on the foundation and increased assembly work due to unevenness)  
Apply the gravel mixture to the subsoil and level (no excavation necessary)

2. Connections:  
- 16 A, CEE-plug  
- Sewage pipe, DN 90  
- Cold water connection: 19 mm (3/4"), lockable  
--> must be routed by the customer to the location according to the drawing



4. Forklift suitable for the terrain  
Load capacity = 2 t, min. lifting height = 4.2 m  
-> must be provided by the customer before the start of assembly  
-> alternatively: unloading of individual parts by hand with 8 people possible, is to be taken over by the customer

5. Access possibility for articulated lorries directly to the site.  
Length = 18.70 m, height = 4 m, width = 2.55 m  
-> alternatively: unloading of individual parts by hand with 8 people possible, is to be taken over by the customer

6. Unobstructed area for assembly directly at the installation site of ca. 12 x 6 m (see dashed line in drawing)



# MOUNTAIN CHALET 20m² Extend + 8 m²

STROHBOLD

Scale: 1:50 | A3  
Date: 30.01.2024



## FURTHER INFORMATION AND CONDITIONS:

- The surfaces of the construction are treated with LIGNEA RESEDA exterior wood oil special mixture, depending on the color, either with a mixing ratio of 12% or 4% . They can be re-oiled if necessary. Wooden elements exposed to the weather and the floor are oiled with 12%, the remaining elements with 4%. Wooden elements that are exposed to the weather should be re-oiled annually for longer durability.
- If the translucent membrane is damaged due to excessive mechanical stress (vandalism, hurricane), it can be repaired with Tesa-ultra-power-clear repair tape.
- To avoid dampness, the space underneath the construction must be kept free of plants or similar objects. 20 cm of ventilation under the wooden construction must always be guaranteed.
- In case the translucent membrane gets dirty, it can be cleaned carefully either with a telescopic brush or/and cloth with water. If heavily stained, clean it with a PVC (membrane) cleaner.  
Make sure not to damage the surface coating (no high-pressure cleaner, etc.)